






**I** • Installing the machine



**II** • Operation




- 1) Mode of operation switch
- 2) Pressure display
- 3) Pressure regulator
- 4) Access guard for inlet
- 5) Feed ramp
- 6) Rating plate
- 7) Conveyor belt
- 8) Cleaning plate
- 9) Filter
- 10) Steering castor without brake
- 11) Mains connection
- 12) Brine return pipe
- 13) Pickle mixer
- 14) Centrifugal pump
- 15) Steering castor with brake
- 16) Conveying hose
- 17) Pump drive shaft
- 18) Access guard for outlet
- 19) Curing compartment door
- 20) Needle register
- 21) Spring magazine

**①** • Mode of operation switch




- Slow speed < Start >
- Slow speed < ON >
- Stop < OFF >
- High speed < ON >
- High speed < Start >

**③** • Pressure regulator



**⑤** • Feed ramp



13 • Pickle mixer



	Stop
	Soft Mix
	Hard Mix

11 • Mains connection




18 • Access guard





4 • Access guard



19 • Curing compartment door




20 • Needle register



7 • Conveyor belt



9 • Filter



III • Cleaning

